



Programmable Electronic Water Timer



current time	TIME	5:45 PM	moisture sensing (moisture sensor is optional accessory)
water start time	START WATER	5:30 PM	
water duration (1-240 min.)	HOW LONG	45 MIN	
water frequency (4,6,8,12,hrs, 1-7 days)	WATER EVERY	4 HRS	
program status	PROGRAM	ON OFF	
manual	MANUAL	OFF MIN	battery status 50%

Battery Installation

Install 2 AA Alkaline batteries by removing the battery holder from the back of the timer and inserting the batteries. Replace the battery holder.

Please install fresh batteries if the battery status indicates below  on the LCD display.

Please recycle batteries after use.

Please do not use rechargeable battery.

Programming

1. Set Current Time

Press ◀ or ▶ button to decrease / increase time to the current time.

Press ▼ button or wait for 3 seconds to confirm to next step.

Note: The time is set on 12-hour clock. To change to 24-hour clock format, press both ◀ & ▶ and hold for 10 seconds.

To return to 12-hour clock, press both ◀ & ▶ and hold for 10 seconds again

2. Set Water Start Time

Press ◀ or ▶ button to decrease / increase time to the desired watering start time.

Press ▼ button or wait for 3 seconds to confirm to next step.

3. Set How Long

Press ◀ or ▶ to decrease / increase the duration (up to 240 minutes).

Press ▼ button or wait for 3 seconds to confirm to next step.

4. Set Water Frequency

A. There are 11 water frequencies selections available.

B. They are every 4HRS, 6HRS, 8HRS, 12HRS, 1 DAY, 2 DAY, 3 DAY, 4 DAY, 5 DAY, 6 DAY and 7 DAY

C. Use ◀ or ▶ to select desired watering frequency.

D. Press ▼ button or wait for 3 seconds to confirm to next step.

Activate Programming

1. Press ◀ or ▶ button to move the indicator to "ON".

2. Press ▼ button or wait for 3 seconds to confirm "ON" to activate the program.

Disabling the Program

In the case of suspending automatic watering for an extended period,

1. Press ◀ or ▶ button to move the indicator to "OFF".

2. Press ▼ button or wait for 3 seconds to confirm

Manual Watering

During non-watering time, you may activate this mode to start watering.

1. Press ▶ to start set up MANUAL watering duration.

2. Press ◀ or ▶ to decrease / increase the duration (up to 240 minutes).

3. Press ▼ button or wait for 3 seconds to confirm

Installation

Attach timer to faucet and hose. Open the faucet and leave it open.

Water will come on and shut-off at the selected time.

Note: this timer can be programmed before installation.

Care and Maintenance

1. For outdoor use only.

2. Operating water pressure: under 100 PSI.

3. Operating water temperature: 32°F (0°C) ~ 100°F (38°C).

A. Turn off the faucet and remove the timer from the faucet.

B. Manual on the timer to open the valve to drain out water.

C. Remove the batteries.

D. Dry the timer and store the timer in a dry place.