

M I C R O - D R I P S Y S T E M

Precise use of water to plant roots.




MICRO-DRIP SPRINKLER SYSTEM.....P16



MICRO DRIP

Ideally suited for irrigating flower boxes, terrace plants, bushes and shrubs or vegetable plants at the root level



12080



90° Spray Nozzle
4.6mm (3/16")

- Rotating the cap to change the spray angle
- Complete shut-off via flow control valve mechanism on the peg
- Dripper caps can be removed for easy cleaning



12081



180° Spray Nozzle
4.6mm (3/16")

- Rotating the cap to change the spray angle
- Complete shut-off via flow control valve mechanism on the peg
- Dripper caps can be removed for easy cleaning



12083



Shower Spray Nozzle
4.6mm (3/16")

- Provides a lite shower effect
- Complete shut-off via flow control valve mechanism on the peg
- Dripper caps can be removed for easy cleaning



12090



Rotor Sprinkler
4.6mm (3/16")

- Rotation of the nozzle head on swivel mount
- Complete shut-off via flow control valve



12000



Pipe pegs
4.6mm (3/16")

- Used for emitter mounting also for drip tubing



92181



Mist Nozzle
4.6mm (3/16")

- Emitter head can be adjusted upwards or depending on watering needs
- Rotation of the cap allows adjustment of flow
- Dripper caps can be removed for easy cleaning



92182



Drip Nozzle
4.6mm (3/16")

- Emitter head can be adjusted upwards or depending on watering needs
- Rotation of the cap allows adjustment of flow
- Dripper caps can be removed for easy cleaning



23321



Flow Control Valve
4.6mm (3/16")

- Adjust flow and range



23325



Inline Mist Nozzle
4.6mm (3/16")

- Cool down ambient air
- For delicate plants/flowers
- Can be added to pegs (12000) or hung from overhead hoses



23326



Inline Drip Nozzle
4.6mm (3/16")

- Provide a gentle water drops with an adjustable neck
- Adjustable cap allows simultaneous control of flow rate
- Can be added to pegs (12000) or hung from overhead hoses



20831 / 20831E



4-Zone Drip Irrigation Manifold 4.6mm (3/16")

- Designed for 4 zone drip irrigation connections
- Each zone has built-in flow control shut-off valve
- Hand tighten all connection. No tools required!



20804 / 22804



Drip Tap Adaptor 4.6mm (3/16")

- Quick and easy tap conversion to drip irrigation systems
- No special tools or glue required



23333



T-joint 4.6mm (3/16")

- Connect your various hose lengths
- No special tools or glue required
- 3 Openings
- Expand your current system by splitting the tubing



23332



Joiner 4.6mm (3/16")

- Provide a secure connection
- 2 Openings
- Expand your current system by increasing the length of your tubing



22430



Drip End Cap 4.6mm (3/16")

- Tube-end completion
- Add to any emitter



Backflow Preventer

- Improve water supply pressure by preventing back flow in multiple branch hose system
- To prevent backflow of unclean water going backward into the water supply

20422 / 20422E



Pressure Regulator

- Maintaining stable pressure to protect the life of soaker hose
- Made by tough durable plastic and with stainless component

02300-15m / 50m



Drip Pipe 4.6mm (3/16")

- Maximum recommended operating pressure 40 psi
- UV resistant polyethylene resin for long lasting use
- Flexible to handle
- Black in color helps to distinguish it from landscape
- Compatible with all micro drip systems

99079



Micro-Drip Sprinkler System 4.6mm (3/16")

- 2 x Shower Spray Nozzle
- 2 x 180° Spray Nozzle
- 1 x Rotary Micro Sprinkler
- 2 x Drip End Cap
- 1 x Drip Tap Adaptor
- 1 x T-joint
- 1 x Drip Pipe 4.6mm (3/16"), 30 ft.



ARC - FREE SPRINKLER

Multiple flexibility to manage your watering with any garden shape.





ARC FREE ROTOR SPRINKLER SET.....P19

ARC FREE SPRINKLER



Multiple flexibility to manage your watering with any garden shape.





Adjustable Spray Radius
5-360°



Variable Spray Angle
360°



Flow Control
Watering dia. up to
33ft.(10m)




Cut your hose to match the distances between each spike location. To prevent leaks, please cut your hose properly squared. Attach the hoses to the spike by loosening the side hose connectors. Insert the hose into the connector, then tighten the connector, creating a tight fit. Put the STOP end cap at the end or remove the STOP end cap to add additional units.



Rotor Daisy Sprinkler

- Fits for garden hose
- **Watering dia.33ft. (10m) ; coverage : 706sq.ft. (78sq.m)**
- Variable circle arc setting: 5° to 360°
- Tool-free trip arc adjustment
- Flow control
- Snap-fit quick connectors (12313)




Arc-Free Rotor Sprinkler

- Fits for garden hose
- **Watering dia.33ft. (10m) ; coverage : 706sq.ft. (78sq.m)**
- Variable circle arc setting: 5° to 360°
- Tool-free trip arc adjustment
- Flow control
- Snap-fit quick connectors (12312)




DIY Daisy Rotor Sprinkler Set

- Complete with hose, fitting and rotor daisy sprinkler
- 1 set of 50ft (15m) x 1/2" (12.7mm) hose
- 1 set of hose connector
- 3 sets of rotor daisy sprinkler
 - variable circle arc from 5° to 360°
 - tool-free trip arc adjustment
 - **watering dia.33ft. (10m) ; coverage up to 706sq.ft. (78sq.m)**
 - w/ tap connector flow through



NOT LIMITED TO LANDSCAPE DESIGN

Placed in any location to suit your watering need.
 Aim the spray without positioning the spikes, and vary the water flow.
 Add extensions where needed for added height



If your faucet is located in an inconvenient place, you can use the 3-way hose connector to divide your watering needs into two separated watering channels



ACCESSORIES COMPONENTS

For Sprinklers

22337



3-Way Hose Connector

22504



1/2" Hose Connector with 3/4" Female Thread (BSP)

22524



1/2" Hose Connector with 3/4" Male Thread (BSP)

22501



1/2" Hose Connector with Adaptor

22423



Stop End Cap

20504



1/2" Hose Connector with 3/4" Female Thread (NH)

20524



1/2" Hose Connector with 3/4" Male Thread (NH)

51P0298-1



1/2" Riser
 (Use with ARC-FREE SYSTEM and other watering tools)